

Pumped Water Modules (Watermatics) Action for sub-zero temperatures

Please be aware that these units are not designed to work in sub-zero temperatures of frost conditions. When the temperature drops below 1°C please stop using the Watermatic and disconnect from the toilet block / shower / canteen to which the Watermatic is supplying.

Also please remove the drain plugs (small black thumb screws) from the water pump; this is located within the steel box at the end of the Watermatic.

Failure to follow the above will result in the pump / pipework cracking and leaking, this will result in replacement costs and downtime.

To start the Watermatic (once the temperature has risen), replace the bottom drain plug, fill the pump with water from the top drain plug, replace the top drain plug (both plugs finger tight) and restart the unit.

Should anyone wish to discuss in further detail any of the points above, please do not hesitate to contact the office.

Waters Waste Services Ltd.

